



## > OUTILS MANUELS DE POSE INTERVIS<sup>®</sup>

MANUAL FOR INTERVIS<sup>®</sup> SETTING TOOL

### SUR QUELS INTERVIS<sup>®</sup> L'UTILISER ?

Intervis<sup>®</sup> : de M 2,5 à M 16.

### POUR QUELS UTILISATEURS ?

- Techniciens monteur.

### COMMENT UTILISER L'OUTIL ?

- 1 Visser l'Intervis<sup>®</sup> sur l'outil fente vers le bas.
- 2 Positionner l'ensemble sur le trou et visser l'intervis jusqu'à environ 0,1 à 0,2 mm en dessous de la surface de la pièce. En cas d'effort trop important lors de l'insertion utiliser un "tourne à gauche".
- 3 Débloquer l'écrou avec une clé plate puis dévisser l'outil jusqu'à ce qu'il se sépare de l'intervis

### ON WHICH INTERVIS<sup>®</sup> CAN IT BE USED ?

Intervis : de M 2,5 à M 16.

### FOR WHICH USERS ?

- Assembler technician

### HOW TO USE THIS TOOL ?

- 1 Screw the Intervis<sup>®</sup> into the tool : slot downward
- 2 Screw the Intervis<sup>®</sup> into the hole down approximately 0.1 to 0.2mm, and use a wrench in case of insistence.
- 3 Unlock the nut with a latch key and unscrew until it ejects from the Intervis<sup>®</sup>

Outil  
Tool

Ecrou  
Nut

Intervis  
Intervis



1



2



3

